REVERSIBLE BAG

by Novita Estiti © 2010 http://verypurpleperson.com verypurpleperson@gmail.com

Dimensions in approximate:

- from top of straps to bottom of bag: 50 cm / 20 inches
- height: 28 cm / 11 inches
- width: 40 cm / 16 inches

Instructions:

Place pattern on fold, cut 2 of each fabric. We're gonna refer them as set A and set B.

If you want pockets, sew them before going to the next step.



2

Sew the darts.

Put right sides of each set together and sew all bottom edges, leaving the straps part open.



.





Put set B in set A, right sides together, and sew around the straps.

Stop stitching about 20 cm before the tops of the straps.

If your machine has reverse stitch, use it on each end of stitchings to secure it. Clip rounded corners.



.

Turn the right sides out through one of the straps. It will be a bit difficult at first and you're gonna wonder if you're doing it right, but just keep doing it.

You will feel a thug and after that the bag will turn right sides out smoothly.

Pull out each of the remaining straps.









Look! You *almost* have a bag!



8

Press the seams open. Fold seam allowances on straps and press.

Also press edges of bag to make it easier for topstitching.





Sew the straps of each set together. I often sew the straps absent-mindedly and then found out that I've attached them wrong!

So please make sure that you sew each strap to the strap beside it, NOT the strap that is in front of it.





Match the tops seams together and pin all open edges of straps.

You can also use fusible tapes to make sure it is neat. But I will use pins here.



Topstitch all edges of bag. I use different colour thread for the bobbin.



A reversible bag!





This is a free pattern and tutorial

You may use the finished products for both personal and commercial use. Please do not pass off the pattern and tutorial as your own. Thank you!